



Operating Instructions:

Anal Fantasy Elite Ultimate P-Spot Milker allows for the automated prostate massage and vibration to be used together or separately for a variety of unique pleasure experiences.

Locate the following buttons on the bottom of the Ultimate P-Spot Milker for operation:



Vibration Button



Power Button

Automated Prostate Massage:

1. Press and hold power button (⏻) to turn on. The power button will glow red when power is activated.
2. Press the power button again to turn on the automatic prostate massage. Press the power button to cycle through 9 unique functions.
3. To turn off the automatic prostate massage, press and hold the power button until the red light goes off.

Dynamic Vibration:

1. Press and hold power button (⏻) to turn on. The power button will glow red when power is activated.
2. Press the vibration power button (⦿) to turn on vibration. Press the vibration power button to cycle through 9 unique functions.
3. To turn off vibration, press and hold the power button until the red light goes off.

Automated Prostate Massage & Vibration:

1. Press and hold power button (⏻) to turn on. The power button will glow red when power is activated.
2. Press the power button again to turn on the automatic prostate massage.
3. Press the vibration power button (⦿) to turn on vibration.
4. To cycle through 9 functions for massage and/or vibration, press the corresponding massage and/or vibration button.
5. To turn off, press and hold the power button until the red light goes off.

Care Instructions: Rechargeable via the included USB Cord. Cleanup is a snap after the fun with Refresh[®] Toy Cleaner and warm water. Use plenty of Moist[®] Body Lotion for an extra wet, extra wild encounter.



POWER
BUTTON



VIBRATION
BUTTON